

**NeverStrip™**  
FLOOR COATINGS

# NeverStrip Micron Primer™

A NeverStrip Micron Coating



# NeverStrip Micron Primer

NeverStrip Micron Primer™ is applied prior to NeverStrip Vinyl Seal™ to enhance the shine and depth of appearance of the System on vinyl composition tile (VCT). Typically, two or three applications of Micron Primer are desired with burnishing with a white pad following each coat.

NeverStrip Vinyl Seal is then applied and burnished to achieve a completed system.

## Characteristics

- Add shine to a NeverStrip Vinyl Seal™ System on vinyl composition tile (VCT).
- Does not need to be stripped in its normal lifecycle.
- **UV stable**
- **Solids:** 18%
- **VOC:** Content Less than 50 gms/L
- **pH:** 8.5
- Typically dries for recoat or application of Vinyl Seal in 5-15 minutes

## Coverage

4,000 sq ft/Gallon/Coat is typical coverage

## Packaging

One Gallon Plastic Bottle  
One Quart Plastic Bottle



# NeverStrip Micron Primer

2 of 2

## Caution

- Avoid contact with mucus membranes.
- Avoid contact with steel, glass, aluminum, or painted surfaces.
- Close container tightly after each use
- Use within 12 months of purchase
- This product is alkaline.
- Avoid contact with eyes and skin.
- Keep out of reach of children.
- Product may be harmful if inhaled or swallowed.

## Professional Use Only

Not for sale to or resale to the general public. For professional use only.

## Floor Preparation and Application

- 1 Remove any floor finish from the floor and/or clean the floor and let dry removing soil, marks, grease, etc.
- 2 Tack the floor with a NeverStrip supplied tack cloth.
- 3 Shake Micron Primer before use.
- 4 Micron Primer should be lightly sprayed onto a looped NeverStrip supplied microfiber pad to make the pad damp. Then, lightly spray the product onto the clean floor in sections typically 3' \* 5" to 4' \* 6" Sections. Spread the product evenly with the damp microfiber pad within the Section. Move from Section to Section with overlapping to avoid skips.
- 5 Allow Micron Primer to dry for typically 10-15 minutes. A fan may be helpful with higher humidity to aid the drying. Do not point the fan directly onto the floor within the first 5 minutes.
- 6 Burnish after each application with a 1,500 rpm or greater burnishing machine using a soft white burnishing pad.
- 7 2-3 thin applications of Micron Primer are typical.
- 8 Apply and burnish NeverStrip Vinyl Seal™



800.854.5414  
orders@neverstrip.com  
www.neverstrip.com

**For Hazardous Materials (or Dangerous Goods) Incident:**  
Spill, Leak, Fire, Exposure, or Accident  
**Call CHEMTREC, Day or Night USA and Canada**  
800.424.9300